



4 Professional Choices for Hygienic Wall and Ceiling Cladding

Datasheet 6 Outline Installation Instructions

1. At all times work in a safe manner and to available Method Statements. Make sure you have completed any site induction required.
2. All work should be planned in advance measuring and planning the location of each piece to minimize the use of joints and wastage
3. Joints and edge trims are fitted to the wall through their back sections with stainless screws and plugs or MS adhesive. The bottom may be finished with Proclad Maxbash skirting depending on the floor finish
4. Proclad PU adhesive is applied to the clean and dry substrate or panel. Datasheet 2 for further information.
5. Panels are secured and sealed to the wall by sliding them into the trims
6. Allow min 1.5mm expansion for every linear 1m of panel – in both horizontal and vertical directions. Welding limits allowance for expansion and contraction so should not be used in applications where temperature variation is more than 10 deg C
7. Corners can be finished with one of the selection of Proclad corners trims or can be thermo bent into and around corners with a thermoformer.
8. For Joint detail see Datasheet 7 and 8.
9. Edge/Bottom detail see Datasheet 10, 11, 12, 13.
10. All joints and edges should be sealed with silicone, when using profiles a small amount of silicone should be placed in the profile recess.
11. Joints may also be hot welded – Datasheet 5

